

Pioneering for You

wilo

Handling and Operating Manual

CTM-HS Control Panel



CTM-HS Control Panel Handling and Operation Manual

Contents

- 1. General.....4**
- 2. Safety.....4**
 - 2.1 Symbols related to explanations in the operation guide.....4
 - 2.2 Staff Training.....4
 - 2.3 In case of safety rules violation.....4
 - Possible hazards.....4
 - 2.4 Safety rules for operating personnel.....4
 - 2.5 Safety rules for control and installation works.....4
 - 2.6 Unauthorized modification and usage of spare parts4
 - 2.7Unacceptable operating types.....4
- 3. Shipping and interim storage.....4**
- 4. Purpose of use.....4**
- 5. Product information.....5**
 - 5.1 Application5
 - 5.2 Clipboard Coding.....5
 - 5.3 Working Principle.....5
 - 5.4 Product Features / Benefits.....5
 - 5.4.1Control and Signal Functions.....5
 - 5.4.2 Types of Bus5
 - 5.5 Equipment used in clipboard.....6
 - 5.6 Scope of Delivery.....6
 - 5.7 Options / Accessories6
- 6. Electrical connections.....6**
 - 6.1 Pressure switch.....6
 - 6.2 External on / off circuit:6
 - 6.3Protection against water insufficiency.....6
- 7. Start-up.....7**
 - 7.1 Factory settings.....7
 - 7.2 Control of motor rotation7
- 8. Maintenance.....7**
- 9. Display Images and Explanations.....8**
- 10. Reason of failure and resolution.....12**




Figure: 1 (Wall Type)

- 1-Mains Power Switch
- 2-Electric terminals of Motor connection
- 3-Electric terminals of Control connection
- 4-Pump humidity sensor relay
- 5-Auto-manual selector switches
- 6-Current transformers
- 7-Thermal switches
- 8-Contactor
- 9-Isolation transformer thermal power switch
- 10-Isolation transformer
- 11-Phase protection relay
- 12-24 V DC power supply
- 13-PLC & Analog module
- 14-Emergency stop
- 15-Door locks
- 16-Touch screen
- 17-Digital multimeter

" Panel design; The number of pumps may vary depending on the power and selected options "




Figure: 2 (Standing Type)

- 1- Mains Power Switch
- 2- Electric terminals of Motor connection
- 3- Electric terminals of Control connection
- 4- Pump humidity sensor relay
- 5- Auto-manual selector switches
- 6- Current transformers
- 7- Thermal switches
- 8- Star Delta Relay
- 9- Contactor
- 10- Isolation transformer thermal power switch
- 11- Isolation transformer
- 12- Phase protection relays
- 13- 24 V DC power supply
- 14- PLC & Analog module
- 15- Emergency stop
- 16- Door lock
- 17- Touch screen
- 18- Digital multimeter

" Panel design; The number of pumps may vary depending on the power and selected options "

1. General

Installation and operating should only be carried out by qualified personnel!

Installation and operating instructions are part of the device. It should be available at the side of the device as a source for reference at any time. Completely observing this manual is essential for proper use of the device and proper operation. The installation and operating manual conforms to the device model and the current safety technical norms at the time of printing.

2. Safety

This user manual contains basic explanations that should be taken into account during installation and operation. For this reason, this manual must be read by the installer and the relevant operator during installation and operation. Not only the general safety instructions under this basic safety title but also the special safety instructions added under the following points must be taken into consideration.

2.1 Symbols related to explanations in the user manual

In this operating guide, the safety rules if not followed that may cause injuries and handicaps are indicated by the following symbol.



The warnings against electric shock are specified by the following symbol.



For the purpose of specifying safety rules that may cause damage to machinery, equipment or systems when not in compliance

ATTENTION!

Symbol is used.

2.2 Staff education

The personnel performing the installation must have been properly trained for these operations.

2.3 Dangerous hazards if the safety rules are not observed

Failure to comply with the safety instructions may result in personal injury and damage to the equipment. Failure to comply with the safety rules will also invalidate compensation claims that may arise due to possible injuries. Failure to comply with the rules in general can lead to the following negative facts:

- The important functions of the equipment are disabled,
- Personnel injuries resulting from electrical or mechanical reasons.

2.4 Safety rules for operating personnel

The current legislation on the prevention of accidents should be respected. Necessary precautions should be taken against the hazards that may be caused by electricity. Hazardous electrical hazards must be considered and the directives of the local electricity distribution companies must be respected.

2.5 Safety rules for control and installation works

The business manager should ensure that all control and installation work is carried out by authorized and qualified specialist personnel and that they have information at a sufficient level regarding to the details given in the user manual. In principle, the work on the system should only be carried out when the system is in a completely stopped position.

2.6 Unauthorized modification and spare parts use

Changes to the appliance are only possible with the manufacturer's approval. The use of spare parts recommended by the manufacturer ensures that the safety is complete. The use of other parts may invalidate claims for compensation.

2.7 Unacceptable operating types

The operating safety of the supplied equipment is only guaranteed in case of operation in working condition indicated in paragraph 4 of the operating instructions. The operating limit values given in the catalog or brochures should never be exceeded.

3. Shipping and interim storage

ATTENTION!

The panel is shipped from the factory in boxes or on a pallet, protected against dust and moisture.

Receiving the product:

- The transport should be checked for damage,
- If any transport damage is detected, the transport company must make necessary initiatives.

During transport:

- Always use suitable lifting devices and take the safety nets to prevent parts from falling,



- Secure the product on a flat pallet, use a suitable pallet truck for transportation.

- Never stop under suspended loads, use a cage during lifting and secure the product straight into the cage.
- Ensure that the panel is stable and stable in storage and transport, and before the installation work in a safe place. The control unit must be protected against nausea and mechanical damage.

ATTENTION! The control unit must be protected against humidity and mechanical damage. Environment between -10 ° C and + 50 ° C Should not be used except this temperature range

4. Purpose of use

CTM-HS control panel is designed for automatic and safe operation of wet well / lifting station applications in infrastructure waste water facilities. It is suitable for automatic control with 4-20 mA analog level sensor of up to 4 pumps.

5. Product information



5.1 Application

Automatic control of pump system with maximum 4 pumps, with 4–20 mA analog level sensor.

5.2 Panel Coding Sample

Sample: CTM-HS 2X2.2 DOL
 CTM-HS System with analog level sensor
 2 Number of pumps
 2.2 Nominal power of each pump P2 [kW]
 DOL Direct starter
 SD Star Delta starter
 FC With frequency converter
 SS With softstarter

5.3 Working Principle

The system has 2 operating modes;

All together: If there is a minimum water level in the system, the pumps work in such a way that 1 pump will be activated at each level as the water level continues to rise. Pumps continue to operate until the water in the system is drained and below level 1, and all pumps are switched off at the same time as the water level falls below level 1.

One by one: If there is a minimum water level in the system, the pumps work in such a way that 1 pump at each level is activated as the water level increases. When the water in the system starts to drain and every 1 level decreases, 1 pump is deactivated.

5.4 Product Features / Benefits

- Lockable main switch
- Manual–0–Automatic switch
- Phase protection
- Auto test
- Emergency stop
- External on/off
- General operation / General fault signals
- Individual operation / Individual fault signals
- Automatic pump change in case of failure
- Color touch screen for all values and operating status
- Delay times of pump on and off
- Individual operating/recovering hours of pumps
- Resetting the pump operating time

- Automatic pump replacement
- Total time of system operation
- With the digital multimeter, voltage, ampere and Hz values of the system can be monitored
- Moisture sensor relay for motor water leaks
- Setting external setpoint with 4–20mA
- External 4–20mA flowmeter input
- 4–20 mA level signal output
- Spare level sensor input
- Digital–Analog signal tracking
- Maintenance settings by date and time
- Set history tracking
- Last 100 alarm can be seen
- Graphic monitoring screen
- Advanced options and operation options
- Protection class IP65
- Insulated transformer
- Inside interior lighting
- Cooling fan
- Heater
- External spare fuse output
- External fan output

5.4.1 Control and Signal Functions

- Operation / stop with external free contact
- SSM general fault signal
- SBM general operation signal
- Individual error signal for each pump
- Individual operation signal for each pump
- Horn output 24 VDC
- Max. Level of free contact output

5.4.2 Bus Types

- Modbus
- Ethernet + Web gate

5.5 Equipment used in Panel

The structure of the control panel is designed according to power of connected pumps.

- Main switch: It switches the control device on / off. (Fig. 1 and 2, no.1)
- Current transformer (Fig. 1 and 2, no.6)
- Phase sequence relay (Fig. 1– no.11 and Fig. 2– no.12)
- Touch screen: Operational data (see. Menus) and operation The status is indicated by the color change of the background lighting. It provides menu selection and parameter entry via the touch screen. (Fig.1 No:16, Fig.2 No:17)
- Memory programmable logical controller (PLC): The network is made up of modular construction. (Fig.1 No:13 Fig.2 No:14)
- Power supply: 24V DC power supply (Fig.1 No:12, Fig.2 No:13)

- Protective / protection combinations: There are safeguards for the operation of the pumps: Overcurrent fuse thermal isolator (current rating: 0.58 IN) Time relay and contactors for star-to-delta transformation. (Fig.1 No: 7 Fig.2 No:7-9)
- Manual-0-automatic switch: Switch for selection of pump operation types. (Fig.1 and Fig.2 No:5) "Manual" (emergency operation on mains/test operation: motor protection available)"0" (pump off – can not be activated via PLC) "automatic" (pump is released via PLC for automatic operation)
- Emergency stop button



ATTENTION!

The emergency stop button does not interrupt the power supply, only stops the operation of the system. When you intervene to the control panel, cut off the input power supply. (Figure 1 No:20, Figure 2 No:18)

Technical Specifications	
Mains supply voltage (V)	3~400 V, 50/60 Hz
Nominal current (A)	See. Product label
Protection type	IP54
Maximum permissible ambient temperature	50 °C
Mains insurance	According to the circuit plan

5.6 Delivery scope

- Control panel – WILO CTM-HS
- Electrical Circuit Diagram
- Installation and operating instructions

5.7 Options / Accessories

CTM-HS system can optionally be equipped with the options listed below. They must be ordered exclusively. The connection of the pumps must be carried out on the contact site in accordance with the circuit diagram,

- GSM module
- GPRS module
- Thermal magnetic breaker
- Leakage current protection relay
- Frequency converter
- Soft starter
- UPS
- Surge arresters
- In-board socket 220V-380V



6.Electrical connections

The electrical connection must be carried out by trained personnel in accordance with the regulations of the regional electricity distribution company.

Network connection:

Explanations regarding the installation and operating instructions of the whole equipment must be taken into account.

Pump network connections

ATTENTION!

Take into account the installation and operating instructions of the pump!

6.1 Pressure sensor

According to the installation and operating instructions, connect the 4/20 mA pressure sensor to the terminals according to the circuit diagram. Use shielded cable, place shield in one-sided circuit box

ATTENTION!

Do not apply external voltage to the terminals!

6.2 External on / off circuit:

According to the circuit plan, the tele (remote) on / off circuit can be connected via the potential free contact (opener) after the bridge has been removed with the corresponding terminals (pre-assembled by the factory).

External on / off circuit	
Contact off	Auto ON
Contact on	Auto OFF, reporting on the screen with a symbol.
Contact load	24 VDC / 10 mA

ATTENTION!

Do not apply external voltage to the terminals!

6.3 Dry running protection

According to the circuit plan, the dry running protection circuit can be connected via the potential free contact (opener) after the bridge has been removed with the corresponding terminals (pre-assembled by the factory).

Dry running protection	
Contact off	Water level is ok
Contact on	Water level is not ok
Contact load	24 VDC / 10 mA

ATTENTION!

Do not apply external voltage to the terminals!

7. Operation

We recommend that the device be operated by WILO Customer Service. Before the first commissioning, the cables on the side of the building must be checked for proper connection and especially grounding. The individual precautions must be taken from the installing and operating guide for the complete equipment.

ATTENTION!

**All connection terminals must be tightened before commissioning.
Do not cover the fan inlet and outlet filters.**

7.1 Factory settings

Preset of the control panel was made in the factory. The factory setting can be recreated by the WILO Service.

7.2 Control of motor rotation

The motor is manually started. If labelled current is equal or close to value, direction of motor rotation is considered correct. If current is less than labeled current, this means that the motor is in the opposite direction. If the motor is vibrating and making too much noise, there is a possibility that the motor is in the opposite direction. From the panel screen the water levels must be monitored and the decrease in water levels must be noted. If the water levels are dropping slowly the motor is in opposite direction, if the water levels are dropping rapidly then the motor rotation is right.

8. Maintenance

Periodic maintenance and repair works are only carried out by WILO Pompa Sistemleri A.Ş. By qualified personnel who are authorized and authorized by the authorized service department!



There is a life-threatening hazard due to electric shock when working on electrical devices.

- During all maintenance and repairs, the control unit must be switched off and must be picked up in such a way that it can not be re-started by unauthorized personnel.
- Damage that may occur in the connection cable may only be rectified by a qualified electrician.

The following maintenance by the user must be visually checked once a month;

- The control cabinet must be kept clean, If dusting occurs, it should be cleaned with a dry cloth outside the panel.
- The filter elements in the fans should be checked by removing the fan cover by means of the tabs on the fan without opening the panel cover, cleaned with air and cleaned if necessary.



ATTENTION!

The leakage current protection relay must be installed in the power line where the control panel is connected.

Do not cover the fan inlet and outlet filters.

9. Spare parts

Spare parts is ordered through the services authorized by WILO Pompa Sistemleri A.Ş..

The spare parts list is on the back page of the electricity project.

10. Authorized services

You can find a list of services authorized by WILO Pompa Sistemleri A.Ş. :

<http://www.wilo.com.tr/anasayfa/servis-destek/yetkili-servisler/>

11. Misuse

- The control panel cover must be kept closed and locked.
- Do not switch off the power supply switch of the control panel except for periodic maintenance (controlled conditions).
- Do not intervene in the panel without interrupting the power supply.
- Do not place any material on or in front of the control panel.
- By inserting an isolated carpet in front of the control panel and pressing on the carpet Interfere with the board.
- Do not pull the power supply line out of the control cabinet.

12. Safety and Environmental Instructions

Waste disposal and Complying with WEEE Regulation on Control of Hazardous Wastes:










This product is in accordance with EU WEEE Instructions(2012/19/EU). This product includes a symbol that is used for management of waste from electric and electronic equipment. Within the European Union this symbol may be present on the product, packing or its relative manual. This symbol means that the relevant electric or electronic product must not be disposed alongside household waste products. The relevant products must be transported, recycled or disposed of according to the following statements:






- These products must only be handed over to a certified disposal center.
- Comply with local law at all times! For the proper disposal procedure please contact local authorities, nearest disposal center or the dealer where you have made your purchase. For more information on recycling visit; <http://www.wilo-recycling.com> .






Packing Information Ambalaj Bilgileri : Packaging of this product is made from recycleable materials that comply with National Environmental Legislation. Do not dispose of packaging materials with household or other waste. Take these materials to recycling points designated by local authorities.

Technical differences may apply!







13. Screen Views and Explanations









Screen View	Descriptions
	<p>1. Monitoring page</p> <p>After the panel is energized the Monitoring page is opened. This page includes: the current water height, operation / failure conditions of the pumps, monitoring of the system, warnings and manual operation of the pumps.</p>
	<p>Manual operation of the pumps</p> <p>Pumps can be operated manually by touching the pump images on the monitoring page. To do this, the user must first be selected and the corresponding user password must be entered. Follow these steps to enter your password; Touch the  button on the monitoring screen.</p> <p>The password entry screen appears after the user is selected. Touch the  button to open the keypad with numbers. Touch the  button after entering the password. The monitoring screen opens automatically after the Enter button is touched. Touching the pump image in the monitoring screen opens a small screen to manually control the pump.</p>
	
	
	
	









Screen View	Descriptions
 	<p>Main menu</p> <p>In order to open the main menu, touch the  button at the bottom left of the monitoring page.</p>
	<p>2. Settings page</p> <p>The service password or the operator password is entered by touching the  button on the main menu.</p>
	<p>2.1. Operator settings page</p> <p>Touching the  button on the Settings page opens the Operator Settings page.</p>










Screen View	Descriptions
	<p>2.1.1. Working settings page</p> <p>The working settings page is accessed by touching the  button on the Operator Settings page. Pumps can be operated manually and put into maintenance mode via this page. Touch the  button below the pump image to put the pump into maintenance mode.</p>
	<p>2.1.2. Level setting page</p> <p>The level settings page is reached by touching the  button on the Operator Settings page. Stopping level and working levels are entered via this page as much as the number of pumps. When the water level reaches each of these entered operating levels, 1 pump runs in sequence. If the pump does not provide enough water level to reach the stopping level, the 2nd pump runs in the order. When the water level begins to drop and falls below the stop level, the pumps are deactivated.</p>




Screen View	Descriptions
	<p>2.2. Service settings page</p> <p>The service settings page is accessed by touching the  button on the settings page.</p>
	<p>2.2.1. Installation settings page</p> <p>The installation settings page is accessed by touching the  button on the Service settings page. Installation of the system is done via this page. Enter the value by pressing the corresponding figure.</p>
	<p>2.2.2. Delay time settings page</p> <p>The Delay time settings page is accessed by touching the  button on the Service settings page. The time settings of the system are made on this page, the values are entered by touching the corresponding number. Pump take in delay time; the pumps are activated after this delay time. Pump take out delay time; when not needed, the pumps are deactivated after this time. Pump run feedback fault delay time; This time is counted after the command is run to the pump, and after this time if the pump fails then the system fails. If the external fan working time is 0, the external fan remains permanently off, if a value other than 0 is entered, this will work for the entered operation time, the external fan remains off for the waiting time and restarts at the end of the waiting period and starts counting the working time again.</p>




Screen View	Descriptions
	<p>Help pages</p> <p>The help pages are accessed by touching the  buttons in the lower right corner of the menu pages. The help page contains descriptions about the currently open page.</p>
	<p>2.2.3. Pump settings page</p> <p>The pump settings page is accessed by touching the  button on the Service settings page. Operation of the pumps is done via this page and the value is entered by pressing the corresponding figure. If any pump runs without stopping until the maximum continuous running time, the running pump stops and another pump starts running. Overswitch fault limit; If the pump enters the number of times entered in an hour then the system will fail. The number of PTC fault reset; the errors that are received during the day are automatically reset as the number entered here. Pump current limit is the max current limit of the pump. The working principle is selected via the taking pump out type.</p>
	<p>2.2.4. Working hours settings page</p> <p>The working hours settings page is accessed by touching the  button on the Service settings page. This page monitors the working and waiting times of the pumps and resets them.</p>





Screen View	Descriptions
<div></div> <div></div>	<p>2.2.5. Screen settings page</p> <p>Screen settings page is accessed by touching the  button on the Service settings page. Screen saver settings are made on this page.</p>
<div></div>	<p>Screen configuration</p> <p>The panel settings page is accessed by touching the  button at the bottom of the screen settings page. This page adjusts the touch sensitivity of the screen.</p>
<div></div>	<p>2.2.6. Routine maintenance settings page</p> <p>Routine maintenance settings page is accessed by touching the  button on the service settings page. The next maintenance date and time are entered on this page. After maintenance press the  button for start the time again.</p>

Screen View	Descriptions
	<p>2.3. Options page</p> <p>The options page is accessed by touching the  button on the Settings page. This page selects the optional features in the system. If these features are added to the system, they must be activated from this page.</p>
	<p>2.4. Communication page</p> <p>The communication page is accessed by touching the  button on the Settings page.</p>
	<p>2.4.1. Modbus settings page</p> <p>The Modbus settings page is accessed by touching the  button on the Communication page. Modbus communication address and speed settings are entered via this page.</p>
	<p>2.4.2. Ethernet settings page</p> <p>The Ethernet settings page is accessed by touching the  button on the Communication page. Ethernet communication settings are entered via this page.</p>

Screen View	Descriptions
	<p>2.4.3. GSM settings page</p> <p>The GSM settings page is accessed by touching the  button on the Communication page.</p>
	<p>2.5. Date & Time settings page</p> <p>The Date and Time settings page is accessed by touching the  button on the Settings page. The date to be set via this page is entered and the  button is touched.</p>
	<p>3. System data page</p> <p>The system data page is accessed from the Main menu page by touching the  button. Pages that can be viewed about the system data are accessed via this page.</p>
	<p>3.1. Pump data page</p> <p>The pump data page is accessed from the System data page by touching the  button. The working and waiting times of the pumps are monitored from this page.</p>

Screen View	Descriptions
	<p>3.2. I/O Monitoring page</p> <p>The I/O Monitoring page is accessed from the System data page by touching the  button. This page provides access to the pages analog / digital inputs and outputs can be viewed on the PLC.</p>
	<p>3.2.1. Digital I/O page</p> <p>The digital I/O page is accessed by touching the  button on the I/O Monitoring page. The physical digital inputs and outputs on the PLC are monitored from this page.</p>
	<p>3.2.2. Analog I/O page</p> <p>The Analog I/O page is accessed by touching the  button on the I/O Monitoring page. Analog inputs and outputs on the PLC are monitored from this page. It is also possible to watch the battery level, analog module error and communication status.</p>

Screen View	Descriptions
	<p>3.3. Set logs page</p> <p>Set logs page is accessed by touching the  button on the System data page. This page displays the water level set changes made previously. On this screen, it is possible to monitor 100 sets of past changes.</p>
	<p>4. Alarms page</p> <p>The Alarms page is accessed from the System data page by touching the  button. This page contains buttons for Active alarms and History alarms.</p>
	<p>4.1. Active alarms page</p> <p>The active alarms page is accessed by touching the  button on the Alarms page. This page monitors current alarms in the system.</p>
	<p>4.2. Alarm history page</p> <p>The Alarm history page is accessed by touching the  button on the Alarms page. This page displays previously created and resetted alarms. This screen can display up to 100 alarms.</p>

Screen View	Descriptions
	<p>5. Project informations page</p> <p>The project information page is accessed by touching the  button on the Home page. In this page; the project name, project author and PLC firmware informations are monitored.</p>
	<p>Changing the system language</p> <p>To change the system language, touch the  button on the Home screen and touch the flag image to be changed.</p>

13. Failure causes and possible solutions

Definition of Problem	Possible reasons	Solution recommendation
Pump operates short time and stops	Ground is not connected	Connect the grounding cable.
	The sensor reads incorrectly or interrupts the signal	Check the sensor cable.
	May Sensor value not entered or entered wrong	Enter the sensor type-meter setting from the Level settings-3 page.
Analog sensor / Analog module fault	Sensor cable faulty	Change the cable.
	Sensor may be faulty	Disconnect the sensor cable ends from the panel sensor (2) k ohm resistor is connected instead, if the error is erased the sensor is faulty
	Sensor cable ends are reversed	Replace the sensor cable ends.
Height of water read on the panel with actual water height is different	Sensor values may be misrepresented. The sensor value can be set low or high to allow equal perception	Enter the sensor type-meter setting from the Level settings-3 page.
	PLC analog input faulty	Replace the analog module.
Triangle mark on screen	PLC can not communicate, PLC program may be deleted or there is a problem with communication cables	Check the communication cable, try to reload the program if the problem persists
No text or images on screen	No display power supply.	The power supply should be checked if the display supply does not measure 24VDC.
There is no fault on the screen, system doesn't work.	Pumps left manually	Set pump to automatic position from manual control page
Earth fault and motor short circuit faults	Motor winding problems	The motor windings are measured.
	Short circuit in contactor	The contactor is changed.
	Touching the housing in the cables	A short-circuit check is performed and it is resolved if necessary.
	There may be looseness in the terminals.	Check the terminals.

GARANTİ BELGESİ

Bu belge 6502 sayılı Tüketicinin Korunması Hakkında Kanun ve Garanti Belgesi Yönetmeliği'ne uygun olarak düzenlenmiştir.

GARANTİ ŞARTLARI

1. Garanti süresi, malın teslim tarihinden itibaren başlar ve 2 yıldır.
2. Malın bütün parçaları dahil olmak üzere tamamı garanti kapsamındadır.
3. Malın ayıplı olduğunun anlaşılması durumunda tüketici, 6502 sayılı Tüketicinin Korunması Hakkında Kanunun 11 inci maddesinde yer alan;
a- Sözleşmeden dönme,
b- Satış bedelinden indirim isteme,
c- Ücretsiz onarılmasını isteme,
ç- Satılanın ayıpsız bir misli ile değiştirilmesini isteme,
haklarından birini kullanabilir.
4. Tüketicinin bu haklardan ücretsiz onarım hakkını seçmesi durumunda satıcı; işçilik masrafı, değiştirilen parça bedeli ya da başka herhangi bir ad altında hiçbir ücret talep etmeksizin malın onarımını yapmak veya yaptırmakla yükümlüdür. Tüketici ücretsiz onarım hakkını üretici veya ithalatçıya karşı da kullanabilir. Satıcı, üretici ve ithalatçı tüketicinin bu hakkını kullanmasından müteselsilen sorumludur.
5. Tüketicinin, ücretsiz onarım hakkını kullanması halinde malın;
- Garanti süresi içinde tekrar arızalanması,
- Tamiri için gereken azami sürenin aşılması,
- Tamirinin mümkün olmadığının, yetkili servis istasyonu, satıcı, üretici veya ithalatçı tarafından bir raporla belirlenmesi durumlarında;
tüketici malın bedel iadesini, ayıp oranında bedel indirimini veya imkân varsa malın ayıpsız misli ile değiştirilmesini satıcıdan talep edebilir. Satıcı, tüketicinin talebini reddedemez. Bu talebin yerine getirilmemesi durumunda satıcı, üretici ve ithalatçı müteselsilen sorumludur.
6. Malın tamir süresi 20 iş gününü geçemez. Bu süre, garanti süresi içerisinde mala ilişkin arızanın yetkili servis istasyonuna veya satıcıya bildiri tarihi, garanti süresi dışında ise malın yetkili servis istasyonuna teslim tarihinden itibaren başlar. Malın arızasının 10 iş günü içerisinde giderilememesi halinde, üretici veya ithalatçı; malın tamiri tamamlanıncaya kadar, benzer özelliklere sahip başka bir malı tüketicinin kullanımına tahsis etmek zorundadır. Malın garanti süresi içerisinde arızalanması durumunda, tamirde geçen süre garanti süresine eklenir.
7. Malın kullanma kılavuzunda yer alan hususlara aykırı kullanılmasından kaynaklanan arızalar garanti kapsamı dışındadır.
8. Tüketici, garantiden doğan haklarının kullanılması ile ilgili olarak çıkabilecek uyuşmazlıklarda yerleşim yerinin bulunduğu veya tüketici işleminin yapıldığı yerdeki **Tüketici Hakem Heyetine veya Tüketici Mahkemesine** başvurabilir.
9. Satıcı tarafından bu **Garanti Belgesinin** verilmemesi durumunda, tüketici **Gümrük ve Ticaret Bakanlığı Tüketicinin Korunması ve Piyasa Gözetimi Genel Müdürlüğüne** başvurabilir.

Üretici veya İthalatçı Firma:

WILO Pompa Sistemleri San. ve Tic. A.Ş.

Orhanlı Mah. Fettah Başaran Cad. No:91 Tuzla

İstanbul / TÜRKİYE

Tel : (0216) 250 94 00

Faks : (0216) 250 94 07

E-posta : servis@wilo.com.tr

Satıcı Firma

Ünvanı

Adresi

Telefonu

Faks

E-posta

Fatura Tarih ve Sayısı

Teslim Tarihi ve Yeri

Yetkilinin İmzası

Firmanın Kaşesi

WILO Pompa Sistemleri San. ve Tic. A.Ş.

Orhanlı Mah. Fettah Başaran Cad. No:91

Tuzla, 35950 İstanbul / TÜRKİYE

T: (0216) 250 94 00 F: (0216) 250 94 04

Aradolu Kurumlar Y.Ş. 011 000 0337

Malın

Cinsi : ELEKTRİK PANOSU

Markası : WILO

Modeli :

Malın

Garanti Süresi : 2 yıl

Azami Tamir Süresi : 20 iş günü

Bandrol ve Seri No :

GARANTİ İLE İLGİLİ OLARAK MÜŞTERİNİN DİKKAT ETMESİ GEREKEN HUSUSLAR

WILO Pompa Sistemleri San. ve Tic. A.Ş. tarafından verilen bu garanti, aşağıdaki durumları kapsamaz:

1. Ürün etiketi ve garanti belgesinin tahrif edilmesi.
2. Ürünün kullanma kılavuzunda yer alan hususlara aykırı ve amaç dışı kullanılmasından meydana gelen hasar ve arızalar.
3. Hatalı tip seçimi, hatalı yerleştirme, hatalı montaj ve hatalı tesisattan kaynaklanan hasar ve arızalar.
4. Yetkili servisler dışındaki kişiler tarafından yapılan işletmeye alma, bakım ve onarımlar nedeni ile oluşan hasar ve arızalar.
5. Ürünün tüketiciye tesliminden sonra nakliye, boşaltma, yükleme, depolama sırasında fiziki (çarpma, çizme, kırma) veya kimyevi etkenlerle meydana gelen hasar ve arızalar.
6. Yangın, yıldırım düşmesi, sel, deprem ve diğer doğal afetlerle meydana gelen hasar ve arızalar.
7. Ürünün yerleştirildiği uygunsuz ortam şartlarından kaynaklanan hasar ve arızalar.
8. Hatalı akışkan seçimi ve akışkanın fiziksel veya kimyasal özelliklerinden kaynaklanan hasar ve arızalar.
9. Gaz veya havayla basınçlandırılmış tanklarda yanlış basınç oluşumundan kaynaklanan hasar ve arızalar.
10. Tesisat zincirinde yer alan bir başka cihaz veya ekipmanın görevini yapmamasından veya yanlış kullanımından meydana gelen hasar ve arızalar.
11. Tesisattaki suyun donması ile oluşabilecek hasar ve arızalar.
12. Motorlu su pompasında kısa süreli de olsa kuru (susuz) çalıştırmaktan kaynaklanan hasar ve arızalar.
13. Motorlu su pompasının kullanma kılavuzunda belirtilen elektrik beslemesi toleranslarının dışında çalıştırılmasından kaynaklanan hasar ve arızalar.

Yukarıda belirtilen arızaların giderilmesi, ücret karşılığında yapılır.

WILO Pompa Sistemleri A.Ş. Satış Sonrası Hizmetleri

Orhanlı Mah. Fettah Başaran Cad. No:91 Tuzla

İstanbul / TÜRKİYE

Tel : (0216) 250 94 00

Faks : (0216) 250 94 07

E-posta : servis@wilo.com.tr

wilo

10.2018

WİLO Pompa Sistemleri A.Ş.
Orhanlı Mah. Fettah Başaran Cad.
No: 91, 34956, Tuzla, İstanbul
T 0216 250 94 00
F 0216 250 94 01
wilo@wilo.com.tr
www.wilo.com.tr



www.wilo.com.tr

Pioneering for You