


WILO-COF



fr Notice de montage et de mise en service
en Installation and operating instructions

Fig. 1




Fig. 2




Fig. 3







Fig. 4



CONSIGNE DE MANUTENTION

FR

- LA MANUTENTION DU SYSTEME DOIT S'EFFECTUER AVEC UN MATERIEL ADAPTE.
- SECURISER LE SYSTEME AFIN D'EVITER TOUT RENVERSEMENT.
- LES COLLECTEURS NE SONT PAS ADAPTES A LA MANUTENTION DU SYSTEME.



TRANSPORT ADVICE

GB

- LIFTING OF THE BOOSTER MUST BE DONE WITH SUITABLE HANDLING EQUIPMENT.
- SECURISE THE SYSTEM AGAINST OVERTURNING.
- MANIFOLD MUSTN'T BE USED TO LIFT THE BOOSTER.

1. General

These installation and operating instructions are an integral part of the product. They must be kept readily available at the place where the product is installed. Strict adherence to these instructions is a precondition for the proper use and correct operation of the product.

These installation and operating instructions conform to the relevant version of the product and the underlying safety standards valid at the time of going to press.

1.1 Applications

The main function of the booster pump is to maintain the pressurization of and supply to a fire hose network for the protection of miscellaneous buildings (hospitals, blocks of flats, schools, industrial facilities, trade centres,...).

1.2 Technical characteristics

- Max. service pressure : 10 bar
- Max. water temperature : + 45°C
- Max. ambient temperature : + 40°C
- Voltage : 3-phase 230/400V

Make sure that the overall installation complies with standard NFC 15100.

2. Safety

These instructions contain important information which must be followed when installing and operating the pump. It is therefore imperative that they be read by both the installer and the operator before the pump is installed or operated. Both the general safety instructions in this section and the more specific safety points in the following sections should be observed.

2.1 Instruction symbols used in this operating manual

Symbols



General danger symbol.



Hazards from electrical causes.



NOTE:

Signal words:

DANGER! Imminently hazardous situation. Will result in death or serious injury if not avoided.

WARNING! Risk of (serious) injury. 'Warning' implies that failure to comply with the safety instructions is likely to result in (severe) personal injury.

CAUTION! Risk of damage to the pump/installation. 'Caution' alerts to user to potential product damage due to non-compliance with the safety instructions.

NOTE! Useful information on the handling of the product.

It alerts the user to potential difficulties.

2.2 Personnel qualification

The personnel installing the pump must have the appropriate qualification for this work.

2.3 Risks incurred by failure to comply with the safety instructions

Failure to comply with the safety precautions could result in personal injury or damage to the pump or installation. Failure to comply with the safety precautions could also invalidate any claim for damages.

In particular, failure to comply with these safety instructions could give rise, for example, to the following risks:

- Failure of important pump or system functions,
- Failure of specified maintenance and repair methods.
- Personal injury due to electrical, mechanical and bacteriological causes.
- Damage to property.

2.4 Safety instructions for the operator

The relevant accident precaution regulations must be observed.

Potential dangers caused by electrical energy must be excluded. Local or general regulations [e.g. IEC, VDE, etc.] and directives from local energy supply companies are to be followed.

2.5 Safety instructions for inspection and assembly

The operator must ensure that all inspection and assembly work is carried out by authorised and qualified specialists who have carefully studied these instructions.

Work on a pump or installation should only be carried out once the latter has been brought to a standstill.

2.6 Unauthorised modification and manufacture of spare parts

Changes to the pump/machinery may only be made in agreement with the manufacturer.

The use of original spare parts and accessories authorised by the manufacturer will ensure safety. The use of any other parts may invalidate claims invoking the liability of the manufacturer for any consequences.

2.7 Improper use

The operating safety of the pump or installation can only be guaranteed if it is used in accordance with paragraph 4 of the operating instructions. All values must neither exceed nor fall below the limit values given in the catalogue or data sheet.

3. Transport and interim storage

When receiving the material, check that there has been no damage during the transport. If any defect has been stated, take the required steps with the carrier within the allowed time. If the delivered material is to be installed later on, store it in a dry place and protect it from impacts and any outside influences (humidity, frost etc...).



CAUTION! The handling should be done by a skilled staff and with an authorized equipment. A sticker on plastic bag reminds the transport advice (Fig. 4). Caution! Handling the system by the manifold can induce leaks.



CAUTION! Handle the pump carefully so as not to alter the geometry and the alignment of the hydraulic unit.

4. Products and accessories

4.1 Description of module (Fig. 1) :

- 1 – Monobloc horizontal BL pump.
- 2 – Attachment frame.
- 3 – Control and automation cabinet.
- 4 – Suction manifold.
- 5 – Discharge manifold.
- 6 – Pump control pressure switch automatic.
- 7 – Pressure gauge.
- 8 – Dry running pressure switch (town version).
- 9 – Bladder tank on collector, or delivered separately, depending on the capacity.
- 10 – Bypass option: for direct water supply without the pumps when the town water pressure is adequate.
- 11 – Capillary.
- 12 – Flow switch to place depending on flow orientation.



NOTE: Each pump is equipped of isolate suction valve, check valve and discharge valve.

4.2 Dry-running protection

The booster is delivered with dry-running protection that depends on the order:

Version "V" with pressure switch connected to module.

Version "B" with float switch to be installed on tank.

4.3 Control cabinet

- Fully automates the booster.
- Sealed, IP 54 protection.
- Thermal protection of motors adjusted in plant to nominal current marked on motor data plate.
- External module safety and power disconnecting switch.
- Closed by key.

On front

Five indicator lights display booster operation:

- 1 Power indicator
- 1 Dry-running indicator
- 1 Pump fault indicator
- 1 On indicator per pump

- 1 three-position switch per pump MANUAL – OFF – AUTO

4.4 Automatic control pressure switch (Fig. 2)

This pressure switch starts and stops the pumps automatically;

it has a single range.

- 1 – PF setting screw.
- 2 – Pressure indication needle.
- 3 – Pf setting screw.
- 4 – Pressure value indication needle.

Note :

PF : Gap of pressure for flow detection.

Pf : Pf + difference (PF-Pf).

PF = Pf + difference (PF-Pf).

Pf must be set up at -0.5 b of pressure of pump at Q=0

4.5 Accessories (optional)

• Isolating valves • Anti-vibration sleeves • Pressure reducing valve • Bladder tank • Foot-valve strainer • float switch • permanent control device of insulation (compulsory for Public Assembly Building)...

5. INSTALLATION

5.1 Room

Ensure the premise door allows free access to the booster pump.

The booster should be installed in a room that easy to reach, normally ventilated and protected from frost.

5.2 Assembly (Fig. 1)

Install on a smooth, level floor on a concrete foundation block with attachment by anchor bolts.

- Place an insulating material (reinforced rubber or cork) under the foundation block to prevent the transmission of flowing-water noise.

5.3 Hydraulic connections

Water can be supplied to the module from a town network (version «V») or from a storage tank (version «B»).

Collectors diameter

COF	Number of pumps	Ø collectors
COF-2BL40-120	2	3"
COF-2BL40-130	2	3"
COF-2BL40-140	2	3"
COF-2BL40-160	2	3"
COF-2BL40-170	2	3"
COF-2BL40-180	2	3"
COF-2BL40-210	2	3"
COF-2BL40-220	2	3"
COF-2BL32-140	2	2"1/2
COF-2BL32-150	2	2"1/2
COF-2BL32-160	2	2"1/2
COF-2BL32-170	2	2"1/2
COF-2BL32-210	2	2"1/2
COF-2BL32-220	2	2"1/2

- The connections to the suction and discharge ports may be made on either the right or the left side; the plugs supplied will be used to blank the unused ports.
- Provide valves on the pipes to be able to isolate the module if work must be done it.
- The flow switch must be mounted with its head upwards and on a horizontal pipe.



CAUTION! If the booster is connected to a network at town water pressure, make sure that the installation can withstand the maximum no-flow pressure of the pump plus the town water pressure.

If not, connect a pressure reducer on the booster outlet.



CAUTION! We strongly recommend to install a pressure reducer-regulator on the water supply pipe to avoid all variations in the module inlet pressure.

- If the module is suction-connected to a tank, the losses of head must not exceed the suction capacity of the pumps.
- The use of a check-valve strainer, with a pipe as large as or larger than the nominal suction diameter, is recommended.
- The installation must always have a bladder tank.

5.4 Electrical connections

The electrical connections and tests must be made by a licensed electrician and comply with applicable local standards.



CAUTION! The control box of the booster cannot be connected to a voltage other than the one for which it was ordered.

All booster electrical control units are connected to the control box.

- Use a cable with 4 conductors (3 phases + earth) to connect three-phase 230 V or three-phase 400 V line power to the terminals (RST) of the disconnecting switch (diagrams inside control box).



DO NOT FORGET TO CONNECT THE EARTH.

Float switch (Version "B")

The float switch, delivered separately, must be installed on the tank and connected to terminals 1 and 2 of the control box by a two conductor cable.

Remove the covers from the terminal blocks to check the electrical connections of the motors (Fig. 3).

6. Starting up

6.1 Pressurising the tanks

Pressurising of tanks to a pressure 0.3 bar less than the pump starting pressure (Pf).

Maximum pressurisation

Tank :

24L 16 bar = 3 bar

- * Safety valve mandatory.

6.2 Filling, degassing

- Check the water supply (tank full enough or town supply working).
- Open the bleed of the pumps and wait for water to flow out steadily before closing.



CAUTION! Never operate the pump dry, even briefly.

6.3 Adjustments

Check of direction of rotation

- Set the pump switches to «OF».
- Close the disconnecting switch. The power indicator should light.
- Open the door of the control box and set the dry-running timer (RME) to zero (0). You should hear a click.
- Set the switch of pump 1 to «Manual»; the pump should start (indicator on control box lit); check that the motor turns the right way.
- Repeat this step for pump 2.
- If a motor turns the wrong way, interchange two phase wires on its terminal block.
- After this operation, set the switches of the pumps back to «Off».

Adjustment of automatic operation pressure switch (Fig. 2)

With the front cover removed :

- Unscrew screw 1, and then screw in screw 3 in order to set pointers 2 and 4 to the highest value on the graduated scale to adjust the pressure switch differential to its minimum.
- Set the reference pressure corresponding to the pump engagement pressure, i.e.:
 - Geometrical building height.
 - Safety guard (0.3 bar).
 - Module differential (0.6/0.8 bar).
 - Difference (PF-Pf).
- Warning Pf must be lower than max pressure of pump (Q=0).
- Screw in screw (item 1) with graduation (Item 2).
- For the pump engagement setting, unscrew screw (item 3) with graduation (Item 4).

Dry-running pressure switch (version«V»)

Pre-set to 1 bar at the plant.

Adjustment if necessary:

- Remove the cover.
- Screw the yellow difference screw all the way in, without locking, then back off a quarter-turn.
- Remove the locking pin from the red disc.
- Fully unscrew the red disc.
- Set the dry-running pressure to the desired value.
Generally: 0.3 bar for pump stopping 1.2 bar for restarting.
- Slowly screw the red disc back in until a click is heard, the red dryrunning light on the control box goes on.
- Refit the locking pin and the cover.

Float switch (Version "B")

Adjust the float so as always to have at least 40 cm reserve water above the inlet and outlet ports of the module, to overcome the resistance of the check-valve strainer.

To check the connection, operate the float switch by hand to light the dry-running indicator on the control panel.

Recommended timer settings

- 1 RMET timer (relay associated with dry-running pressure switch).

This timer provides a safety delay before the pumps are restarted.

- Set the timer to 180 seconds.

- 2 RT1 timer (changeover relay)

This timer stages the starting of the pumps.

- Set in the plant to 1 second (do not change).

- 3 RM timer (hold relay).

This timer is used to extend the operating time of the pump.

- Set the timer to 180 seconds.

This setting serves to limit the number of times the pumps are started.

- 4 RPT timer (Flow switch relay).

This timer is used to filter flow switch during start of pump operating time of the pump.

- Set the timer to 10 seconds.

This setting serves to start the pumps with no flow when low pressure.

Timer settings:

- RMET 10 to 300s
- RT1 0,1 to 3s
- RM 10 to 300s
- RPT 10 to 300s

6.4 Commissioning

NOTE: The maximum service pressure of the installation is equal to the no-flow pressure of the pumps, possibly plus the town water pressure at the booster inlet.

Set the pump switches on the control box to «Auto».

Booster operation is then controlled automatically by the pressure switches and the timers.

7. Maintenance

- The booster needs no special servicing in operation.
- For pumps, refer to the specific handbook supplied together with the module.
- Periodically check the tank inflation.

8. Problems, causes and remedies

Problems	Causes	Remedies
One or both pump not primed	Suction air leak	Check the tightness of all unions of the suction pipe. Check that the suction strainer (version «B») is in fact under water
	Check-valve strainer (version «B») not tight, or obstructed	Check the tightness of the valve; replace if necessary
	Large losses of head at suction	Calculate the losses of head and make sure that they are compatible with NPSH of the pumps
	Town water pressure too low or non-existent	If this recurs, a tank will be needed
	Suction head too great (version "B")	Make sure that the minimum level in the tank is compatible with NPSH of the pumps
	Suction pipe obstructed or valve on suction port closed	Check that the valve is open; clean the pipe if necessary
	The pumps turn the wrong way	Interchange two wires on the motor terminal block
One pump fails to operate	The pump «Fault» light on the control box should be lit	Check the adjustment of the thermal relay and reset it by pressing the red pushbutton
	Fuses faulty or blown	Replace them (check the rating). If the trouble persists, check the current draw of the motor concerned. If it is much higher than the current rating marked on the motor data plate, the motor is faulty and must be replaced
	Pump shaft jammed	Cut off power on the control box, then check that the shaft turns freely. If it is jammed, remove the pump
	Winding fault	Disconnect the terminal block of the motor concerned and check line power on the terminals and the insulation of the stator; if necessary, replace the motor
	Contactor coil burned out	Replace it
Inadequate discharge pressure	Loss of priming of one or both pumps	Check that the suction strainer (version «B») is not taking in air, and that the level in the tank is not too close to the strainer
	Town water pressure less than anticipated minimum pressure	Get in touch with your water board or replace the module (get in touch with us)
	The pumps turn the wrong way	Interchange two wires on the motor terminal block
	One pump is obstructed by foreign bodies	Have the pump dismantled and cleaned
	Supply voltage to motors too low	Measure the voltage on the terminals of the motors
Frequent actuation of relays, frequent starting of pumps	Pump control pressure switch out of adjustment	Check the adjustment; the difference between the high and low pressures must be greater than 0.1 bar
	Capacity of installation too small	Add a tank
	No air in tank	Pressurise the tank or replace the bladder
	Tank bladder pierced	Replace the tank bladder
Frequent actuation of dry-running safety	Dry-running pressure switch setting too high	Correct the pressure switch setting
	Town water pressure drops when pumps start	Adjust the dry-running to the mini. If this recurs, the town's water network is insufficient. Check the pressure during starting of pump. (or consult the water supplier)
Failure of automatic operation	Fuses blown	Change them
	Pressure switches faulty	Check the contacts; if necessary, replace the pressure switch concerned
	Wires disconnected	Check all the connections to the terminal blocks of the control box
	Flow Switch faulty	Check the flow switch triggering on and off, replace it if necessary
Discharge check valve not tight	Valve diaphragm damaged	Replace the valves
No stop of pump	Flow switch in wrong way	Check that arrow on flow switch is in accordance with flow

If no solution can be found, please contact your plumbing and heating specialist or your nearest Wilo Customer Service or representative.

9. Spare parts

Spare parts are ordered via a local specialist dealer and/or Wilo customer service.

In order to avoid queries and incorrect orders, make sure to mention all data indicated on the rating plate when placing your order.

Subject to technical alterations !

D EG – Konformitätserklärung
GB EC – Declaration of conformity
F Déclaration de conformité CE

(gemäß 2006/42/EG Anhang II, 1A und 2004/108/EG Anhang IV, 2,
according 2006/42/EC annex II, 1A and 2004/108/EC annex IV, 2,
conforme 2006/42/CE appendice II, 1A et 2004/108/CE l'annexe IV, 2)

Hiermit erklären wir, dass die Druckerhöhungsanlagen der Baureihe:

Herewith, we declare that the booster sets of the series:

COF

Par le présent, nous déclarons que les types de surpresseurs de la série :

(Die Seriennummer ist auf dem Typenschild des Produktes nach Punkten b) & c) von §1.7.4.2 und §1.7.3 des Anhang I angegeben. / *The serial number is marked on the product site plate according to points b) & c) of §1.7.4.2 and §1.7.3 of the annex I of the Machinery directive 2006/42/EC. / Le numéro de série est inscrit sur la plaque signalétique du produit en accord avec les points b) & c) du §1.7.4.2 et du §1.7.3 de l'annexe I de la Directive Machines 2006/42/CE*)

in der gelieferten Ausführung folgenden einschlägigen Bestimmungen entsprechen:

in their delivered state comply with the following relevant provisions:

sont conformes aux dispositions suivantes dont ils relèvent:

EG-Maschinenrichtlinie
EC-Machinery directive
Directive CE relative aux machines

2006/42/EG

Die Schutzziele der **Niederspannungsrichtlinie 2006/95/EG** werden gemäß Anhang I, Nr. 1.5.1 der 2006/42/EG Maschinenrichtlinie eingehalten. / *The protection objectives of the low-voltage directive 2006/95/EC are realized according annex I, No. 1.5.1 of the EC-Machinery directive 2006/42/EC. / Les objectifs de protection de sécurité de la directive basse-tension 2006/95/CE sont respectés conformément à l'annexe I, no1.5.1 de la directive CE relatives aux machines 2006/42/CE.*

Elektromagnetische Verträglichkeit - Richtlinie
Electromagnetic compatibility - directive
Directive compatibilité électromagnétique

2004/108/EG

und entsprechender nationaler Gesetzgebung,
and with the relevant national legislation
et aux législations nationales les transposant,

angewendete harmonisierte Normen, insbesondere:
as well as following relevant harmonized standards:
ainsi qu'aux normes européennes harmonisées suivantes :

EN ISO 12100
EN 60204-1
EN 61000-6-1:2007
EN 61000-6-2:2005
EN 61000-6-3+A1:2011
EN 61000-6-4+A1:2011

Bevollmächtigter für die Zusammenstellung der technischen Unterlagen ist:
Authorized representative for the completion of the technical documentation:
Personne autorisée à constituer le dossier technique est :

Division Pumps and Systems
Quality Manager – PBU Multistage & Dome:
Pompes Salmson
80 Bd de l'Industrie - BP0527
F-53005 Laval Cedex

Dortmund, 19. Juli 2013

i. A. CBrasse
Claudia Brasse
Head of System Quality

wilo

WILO SE
Nortkirchenstraße 100
44263 Dortmund
Germany

Document: 2109710.02
CE-AS-Sh. Nr. 4137913

Wilo – International (Subsidiaries)

Argentina

WILO SALMSON
Argentina S.A.
C1295ABI Ciudad
Autónoma de Buenos Aires
T + 54 11 4361 5929
info@salmson.com.ar

Australia

WILO Australia Pty Limited
Murrarrie, Queensland,
4172
T +61 7 3907 6900
chris.dayton@wilo.com.au

Austria

WILO Pumpen
Österreich GmbH
2351 Wiener Neudorf
T +43 507 507-0
office@wilo.at

Azerbaijan

WILO Caspian LLC
1014 Baku
T +994 12 5962372
info@wilo.az

Belarus

WILO Bel OOO
220035 Minsk
T +375 17 2535363
wilo@wilo.by

Belgium

WILO SA/NV
1083 Ganshoren
T +32 2 4823333
info@wilo.be

Bulgaria

WILO Bulgaria Ltd.
1125 Sofia
T +359 2 9701970
info@wilo.bg

Brazil

WILO Brasil Ltda
Jundiaí – São Paulo – Brasil
ZIP Code: 13.213–105
T +55 11 2923 (WILO)
9456
wilo@wilo-brasil.com.br

Canada

WILO Canada Inc.
Calgary, Alberta T2A 5L4
T +1 403 2769456
bill.lowe@wilo-na.com

China

WILO China Ltd.
101300 Beijing
T +86 10 58041888
wilobj@wilo.com.cn

Croatia

Wilo Hrvatska d.o.o.
10430 Samobor
T +38 51 3430914
wilo-hrvatska@wilo.hr

Czech Republic

WILO CS, s.r.o.
25101 Cestlice
T +420 234 098711
info@wilo.cz

Denmark

WILO Danmark A/S
2690 Karlslunde
T +45 70 253312
wilo@wilo.dk

Estonia

WILO Eesti OÜ
12618 Tallinn
T +372 6 509780
info@wilo.ee

Finland

WILO Finland OY
02330 Espoo
T +358 207401540
wilo@wilo.fi

France

WILO S.A.S.
78390 Bois d'Arcy
T +33 1 30050930
info@wilo.fr

Great Britain

WILO (U.K.) Ltd.
Burton Upon Trent
DE14 2WJ
T +44 1283 523000
sales@wilo.co.uk

Greece

WILO Hellas AG
14569 Anixi (Attika)
T +302 10 6248300
wilo.info@wilo.gr

Hungary

WILO Magyarország Kft
2045 Törökbálint
(Budapest)
T +36 23 889500
wilo@wilo.hu

India

WILO India Mather and
Platt Pumps Ltd.
Pune 411019
T +91 20 27442100
services@matherplatt.com

Indonesia

WILO Pumps Indonesia
Jakarta Selatan 12140
T +62 21 7247676
citrawilo@cbn.net.id

Ireland

WILO Ireland
Limerick
T +353 61 227566
sales@wilo.ie

Italy

WILO Italia s.r.l.
20068 Peschiera
Borromeo (Milano)
T +39 25538351
wilo.italia@wilo.it

Kazakhstan

WILO Central Asia
050002 Almaty
T +7 727 2785961
info@wilo.kz

Korea

WILO Pumps Ltd.
618–220 Gangseo, Busan
T +82 51 950 8000
wilo@wilo.co.kr

Latvia

WILO Baltic SIA
1019 Riga
T +371 6714–5229
info@wilo.lv

Lebanon

WILO LEBANON SARL
Jdeideh 1202 2030
Lebanon
T +961 1 888910
info@wilo.com.lb

Lithuania

WILO Lietuva UAB
03202 Vilnius
T +370 5 2136495
mail@wilo.lt

Morocco

WILO MAROC SARL
20600 CASABLANCA
T +212 (0) 5 22 66 09
24/28
contact@wilo.ma

The Netherlands

WILO Nederland b.v.
1551 NA Westzaan
T +31 88 9456 000
info@wilo.nl

Norway

WILO Norge AS
0975 Oslo
T +47 22 804570
wilo@wilo.no

Poland

WILO Polska Sp. z o.o.
05–506 Lesznowola
T +48 22 7026161
wilo@wilo.pl

Portugal

Bombas Wilo–Salmson
Portugal Lda.
4050–040 Porto
T +351 22 2080350
bombas@wilo.pt

Romania

WILO Romania s.r.l.
077040 Com. Chiajna
Jud. Ilfov
T +40 21 3170164
wilo@wilo.ro

Russia

WILO Rus ooo
123592 Moscow
T +7 495 7810690
wilo@wilo.ru

Saudi Arabia

WILO ME – Riyadh
Riyadh 11465
T +966 1 4624430
wshoula@wataniaind.com

Serbia and Montenegro

WILO Beograd d.o.o.
11000 Beograd
T +381 11 2851278
office@wilo.rs

Slovakia

WILO CS s.r.o., org. Zložka
83106 Bratislava
T +421 2 33014511
info@wilo.sk

Slovenia

WILO Adriatic d.o.o.
1000 Ljubljana
T +386 1 5838130
wilo.adriatic@wilo.si

South Africa

Salmson South Africa
1610 Edenvale
T +27 11 6082780
errol.cornelius@
salmson.co.za

Spain

WILO Ibérica S.A.
28806 Alcalá de Henares
(Madrid)
T +34 91 8797100
wilo.iberica@wilo.es

Sweden

WILO Sverige AB
35246 Växjö
T +46 470 727600
wilo@wilo.se

Switzerland

EMB Pumpen AG
4310 Rheinfelden
T +41 61 83680–20
info@emb-pumpen.ch

Taiwan

WILO Taiwan Company Ltd.
Sanhong Dist., New Taipei
City 24159
T +886 2 2999 8676
nelson.wu@wilo.com.tw

Turkey

WILO Pompa Sistemleri
San. ve Tic. A.Ş.,
34956 İstanbul
T +90 216 2509400
wilo@wilo.com.tr

Ukraine

WILO Ukraina t.o.w.
01033 Kiev
T +38 044 2011870
wilo@wilo.ua

United Arab Emirates

WILO Middle East FZE
Jebel Ali Free Zone–South
PO Box 262720 Dubai
T +971 4 880 91 77
info@wilo.ae

USA

WILO USA LLC
Rosemont, IL 60018
T +1 866 945 6872
info@wilo-usa.com

Vietnam

WILO Vietnam Co Ltd.
Ho Chi Minh City, Vietnam
T +84 8 38109975
nkminh@wilo.vn



Pioneering for You

WILO SE
Nortkirchenstraße 100
D-44263 Dortmund
Germany
T +49(0)231 4102-0
F +49(0)231 4102-7363
wilo@wilo.com
www.wilo.com